| | | | | | R | EFRIGE | RANT D | RYER | | | | | | | | | |
|------------------------------|-------------------|---|---|---|--------|--------|---------|--------|------|------|----|----|----|----|----|----|----|
| | | | | | "8 HOU | JR SER | VICE CH | HECK L | IST" | | | | | | | | |
| | Month | | | | | | | | | Year | | | | | | | |
| | Days of the Month | | | | | | | | | | | | | • | | | |
| Inspection & Service | Shift | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| Date | 1 | | | | | | | | | | | | | | | | |
| | 2 | | | | | | | | | | | | | | | | |
| | 3 | | | | | | | | | | | | | | | | |
| Inlet Temperature | 1 | | | | | | | | | | | | | | | | |
| | 2 | | | | | | | | | | | | | | | | |
| | 3 | | | | | | | | | | | | | | | | |
| Inlet Pressure | 1 | | | | | | | | | | | | | | | | |
| | 2 | | | | | | | | | | | | | | | | |
| | 3 | | | | | | | | | | | | | | | | |
| Discharge Temperature | 1 | | | | | | | | | | | | | | | | |
| | 2 | | | | | | | | | | | | | | | | |
| | 3 | | | | | | | | | | | | | | | | |
| Discharge Pressure | 1 | | | 1 | | | | | | | | | | | | | |
| | 3 | | | 1 | | | | | | | | | | | | | |
| Refrigerant Suction Pressure | 1 | | | | | | | | | | | | | | | | |
| | 2 | | | | | | | | | | | | | | | | |
| | 3 | | | 1 | | | | | | | | | | | | | |
| Condensate Traps Functional | 1 | | | | | | | | | | | | | | | | |
| | 2 | | | + | | | | | | | | | | | | | |
| | 3 | | | | | | | | | | | | | | | | |
| High Temp. Light | 1 | | | | | | | | | | | | | | | | |
| | 2 | | | | | | | | | | | | | | | | |
| | 3 | | | | | | | | | | | | | | | | |
| Prefilter Drain | 1 | | | | | | | | | | | | | | | | |
| | 2 | | | | | | | | | | | | | | | | |
| | 3 | | | | | | | | | | | | | | | | |
| Prefilter Pressure Drop | 1 | | | | | | | | | | | | | | | | |
| | 2 | | | | | | | | | | | | | | | | |
| | 3 | | | | | | | | | | | | | | | | |
| Afterfilter Pressure Drop | 1 | | | | | | | | | | | | | | | | |
| | 2 | | | | | | | | | | | | | | | | |
| | 3 | | | 1 | | 1 | I | 1 | I | I | I | I | | | I | I | I |

On a monthly basis, dirt and dust should be cleaned form the air-cooled refrigeration condensing unit.

On water cooled models, the cooling water strainer should be cleaned every 3 months and the coolers cleaned annually.